

# Creating a Custom Enclosure for a Drop-in Bathtub

---

Reference Number: **KB-02020**

Last Modified: **April 16, 2025**

---

The information in this article applies to:



## QUESTION

I'd like to use a specific undermount or drop-in bathtub in my plan, but it doesn't appear to have an enclosure. How can I create a custom enclosure for this object?




## ANSWER



Many objects are ready to use as stand-alone objects, however, some objects like drop-in bathtubs are meant to be enclosed. A custom enclosure, or surround, can be created in Home Designer using the Base Cabinet tool.


In this article, we will be using a bathtub object from the **Kohler®** (<https://www.chiefarchitect.com/3d-library/index.php?r=site/detail/998>) Manufacturer catalog. For more information on accessing additional catalogs, please see the [Related Articles](#) section below.

## To create a bathtub enclosure

1. Access the **Library Browser**  , locate a drop-in bathtub that you would like to use in your plan, select it, and place it in your plan.

In this example, the K-1946 Archer 5' Bath symbol from the **Kohler®** (<https://www.chiefarchitect.com/3d-library/index.php?r=site/detail/998>) Manufacturer catalog is used.




2. Using the **Select Objects**  tool, select the bathtub, and click the **Open Object**  edit button.
3. On the **GENERAL** panel of the **Fixture Specification** dialog that displays:




The screenshot shows the 'Fixture Specification' dialog box with the 'General' tab selected. The dialog has a sidebar on the left with 'General', 'Materials', 'Label', and 'Manufacturer'. The main area is divided into sections: 'Object Dimensions' with fields for Width (60"), Depth (30"), and Height (19"), a 'Reset Object Size' button, and a 'Retain Aspect Ratio' checkbox; 'Position' with an 'Elevation Reference' dropdown set to 'From Floor', a 'Flush Mounted' checkbox, and fields for 'Floor to Top' (19") and 'Floor to Bottom' (0"); 'Options' with checkboxes for 'Suppress Adjacent Room Moldings' and 'Reflect Geometry'; and 'Copyright' showing 'Copyright© 2019, Kohler®'. A 3D bathtub model is shown on the right. At the bottom are 'OK', 'Cancel', and 'Help' buttons.

Section	Property	Value	
Object Dimensions	Width:	60"	
	Depth:	30"	
	Height:	19"	
	Reset Object Size	Button	
Position	Retain Aspect Ratio	<input type="checkbox"/>	
	Elevation Reference:	From Floor	Dropdown
	Flush Mounted	<input type="checkbox"/>	
	Floor to Top:	19"	Field
Options	Floor to Bottom:	0"	Field
	Suppress Adjacent Room Moldings	<input type="checkbox"/>	
Options	Reflect Geometry	<input type="checkbox"/>	
	Copyright	Copyright© 2019, Kohler®	

- Make a note of the symbol's **Width**, **Depth**, and **Height**. This is also a good time to change these values if you wish.

- Make any other desired changes, such as the material of the tub by accessing the **MATERIALS** panel.
  - Click **OK** to confirm the changes and close the dialog.
4. Next, navigate to **Build> Cabinet> Base Cabinet**  from the menu, then click to place a single base cabinet in the plan.
5. Using the **Select Objects**  tool, click on the cabinet to select it and select the **Open Object**  edit button.
6. On the **GENERAL** panel of the **Base Cabinet Specification** dialog:



The image shows the 'Base Cabinet Specification' dialog box with the 'General' tab selected. The 'Cabinet Style' is set to 'Standard'. Under 'Size/Position', the 'Width' is 60", 'Height' is 17 1/2" (including countertop), 'Depth' is 6", 'Elevation Reference' is 'From Floor', 'Floor to Top' is 17 1/2", and 'Floor to Bottom' is 0". The 'Countertop' section is checked, with 'Thickness' set to 1 1/2" and 'Overhang' set to 1/8". The 'Uniform' checkbox is checked. At the bottom, there are input fields for 'Front' (1/8"), 'Back' (1/8"), 'Left' (1/8"), and 'Right' (1/8") overhangs, each with a hand icon for adjustment.

- Specify the cabinet's **Width, Height, Depth**, and **Floor to Top/Bottom** values.

The width and height should be close to the width and height of the tub symbol, while the depth will serve as the depth of the surround. In this example, the Width is set to 60", the Height is set to 17 1/2", the Depth is set to 6", and the Floor to Bottom is set to 0".

- Specify the Countertop **Thickness**, along with the **Overhang**.


In this example, the Thickness is set to 1 1/2" and the Overhang is set to 1/8".

Home Designer Pro also has the ability to change the Corner Treatment and Corner Width of the countertop. For example, corners can be Clipped or Rounded, and the Width value can be changed.


- If the bathtub and surround will be positioned against a wall, you may want to define the Backsplash **Height, Thickness**, and other options as well.

7. On the **FRONT** panel:

- Click on the toe kick at the bottom of the preview diagram on the right side of the dialog box, then click the **Delete** button.




- Click on the drawer in the preview and click the **Delete** button a second time.





- Click on the doors in the preview, change the **Item Type** to either a **Door - Panel** or a **Blank Area**, depending on your preference, then verify the **Item Height** is to your liking.

In this example, the Item Type is set to Blank Area and an Item Height of 14 1/2" is specified.






- On the **MATERIALS** panel, select the **Countertop** component, click the **Select Material** button, and browse the library for an appropriate material to serve as the top surface of the enclosure. Perform this same procedure for any other cabinet components you'd like to change.
- Click **OK** to close the dialog and apply your changes.


8. With the cabinet selected, use its **Move**  edit handle to position it alongside the bathtub symbol.




9. With the cabinet still selected, make three more copies of it that you can use to form the other sides of the tub enclosure:

- Click the **Copy/Paste**  edit button;
- Click the **Sticky Mode**  secondary edit button;
- Click three times in an empty space near the tub to place copies of the cabinet.
- When you are finished, click the **Select Objects**  button.

10. The new copies of the base cabinet can now be selected individually, resized, rotated, and moved into position beside the bathtub symbol.






11. Add any desired hardware such as a faucet, then take a **Camera**  view to see the results.



## To block the tub and enclosure together\*

*\*Applies to Home Designer Architectural and Home Designer Pro Only.*

1. In a floor plan view, click the **Select Objects**  tool.
2. Hold down the **Shift** key on your keyboard, then click and drag to draw a rectangular selection marquee around the bathtub, hardware, and base cabinets to select them all as a group.
3. With all of the objects selected, click the **Make Architectural Block**  edit button.
4. You can also click the **Add to Library**  edit button to add this newly formed architectural block to the library for future use in other plan files.

[Return To Top](#)

---

### Related Articles

-  [Creating a Custom Glass Shower \(/support/article/KB-00886/creating-a-custom-glass-shower.html\)](/support/article/KB-00886/creating-a-custom-glass-shower.html)
-  [Creating a Deck Around a Pool or Hot Tub \(/support/article/KB-00853/creating-a-deck-around-a-pool-or-hot-tub.html\)](/support/article/KB-00853/creating-a-deck-around-a-pool-or-hot-tub.html)
-  [Downloading and Updating Library Catalogs \(/support/article/KB-00048/downloading-and-updating-library-catalogs.html\)](/support/article/KB-00048/downloading-and-updating-library-catalogs.html)
-  [Locating and Importing 3D Symbols \(/support/article/KB-00888/locating-and-importing-3d-symbols.html\)](/support/article/KB-00888/locating-and-importing-3d-symbols.html)

