



Deleting Framing

Reference Number: **KB-00197**

Last Modified: **September 9, 2025**

This article also applies to the following legacy products:
Pro


QUESTION

I am using Home Designer Pro or Home Designer 2026 or newer, and I would like to delete framing items that I have generated. How can I do this?

ANSWER

Deleting framing you have generated is easy to accomplish using the Delete Objects dialog.

To delete framing from your plan

1. In a floor plan view, select **Edit> Delete Objects**  from the menu
2. In the **Delete Objects** dialog:

Delete Objects

Delete Scope

☒ All Floors ☐ All Rooms On This Floor ☐ Single Room **Select All** **Clear All**

☐ **Objects**

- ☐ Added Lighting ☐ Doors ☐ Piers
- ☐ Architectural Blocks ☐ Dormers ☐ Plants
- ☐ Cabinets, Base ☐ Electrical ☐ Roof Planes
- ☐ Cabinets, Full Height ☐ Fireplaces ☐ Roof Baseline Polylines
- ☐ Cabinets, Shelves/Partitions ☐ Fixtures ☐ Slab Surfaces
- ☐ Cabinets, Soffits ☐ Furniture ☐ Stairs/Ramps/Landings
- ☐ Cabinets, Wall ☐ Geometric Shapes ☐ Terrain Objects
- ☐ Cameras, Saved ☐ Hardware ☐ Windows
- ☐ Corner Boards/Quoins ☐ Images/Billboards ☐ Wall Hatching
- ☐ Custom Ceilings ☐ Millwork
- ☐ Custom Countertops

☐ **CAD**

- ☐ 2D CAD ☐ Dimensions, Automatic ☐ Pictures
- ☐ 3D CAD ☐ Dimensions, Manual ☐ PDF
- ☐ Text

☒ **Framing**

- ☐ Bearing Line ☐ Direction Lines ☒ Roof Framing
- ☐ Ceiling Framing ☒ Floor Framing ☒ Roof Trusses
- ☐ Custom Ceiling Framing ☐ Other Framing ☐ Wall Framing
- ☐ Deck Framing

☐ **Schedules**

- ☐ Plant Schedules

☐ **Walls**


- ☐ Fencing ☐ Pony Walls ☐ Railing
- ☐ Foundation Walls ☐ Room Dividers ☐ Retaining Walls
- ☐ Other Walls

Delete **Cancel** **Help**


- Choose your desired Delete Scope option. **All Floors** will delete all framing within the entire plan, while **All Rooms On This Floor** will delete all framing from all rooms on the active floor level. The Single Room option does not apply to framing.
- Place checkmarks next to the types of framing you want to delete.

3. Click **Delete** to close the dialog and apply your changes.

To turn off the display of framing

1. While in the view in which you do not want to see the framing displayed, select **Tools> Display Options** 
2. Scroll down to the "Framing..." layers and uncheck the **Disp** column or **Display** checkbox for each layer you

don't want displayed.



3. Click **OK** to apply the change.

Related Articles

- [📄 Creating an Elevation View of Wall Framing in Home Designer \(/support/article/KB-01188/creating-an-elevation-view-of-wall-framing-in-home-designer.html\)](/support/article/KB-01188/creating-an-elevation-view-of-wall-framing-in-home-designer.html)
- [📄 Generating Framing in Home Designer \(/support/article/KB-00462/generating-framing-in-home-designer.html\)](/support/article/KB-00462/generating-framing-in-home-designer.html)
- [📄 Manually Drawing Framing Members \(/support/article/KB-00727/manually-drawing-framing-members.html\)](/support/article/KB-00727/manually-drawing-framing-members.html)