

Removing Roof Gutters in Home Designer Pro

Reference Number: **KB-00308**

Last Modified: **July 29, 2022**

The information in this article applies to:



QUESTION



I need to model a roof without gutters, such as a flat roof or thatched roof style. How can I stop roof gutters from generating on my roof planes?

ANSWER


In Home Designer Pro, gutters can be removed by unchecking the Gutter box in either the Build Roof or Roof Plane Specification dialog.

To remove roof gutters

1. Select **Build> Roof> Build Roof** .


Gutters can also be removed from a specific set of roof planes. Using the **Select Objects**  tool, click on one or more roof planes, then click the **Open Object**  edit button.

2. On the **OPTIONS** panel of the **Build Roof** or **Roof Plane Specification** dialog, uncheck the **Gutter** box located under the Supply section.



3. If you made this adjustment in the Build Roof dialog, the roof must be rebuilt. Check the **Build Roof Planes** or **Auto Rebuild Roofs** box located on the ROOF panel.

This step can be skipped if you removed the gutters using the Roof Plane Specification dialog.



4. Click **OK** to confirm the change and close the dialog.

Related Articles

[Group Selecting Objects \(/support/article/KB-00624/group-selecting-objects.html\)](https://www.chiefarchitect.com/support/article/KB-00624/group-selecting-objects.html)