

# Editing the Material List Display Options in Home Designer Pro

---

Reference Number: **KB-00511**

Last Modified: **July 16, 2015**


---

The information in this article applies to:



## QUESTION

How do I get the Material List Display Options dialog box to appear?

Whenever I select **Tools> Display Options**  I am presented with a Layer Display Options dialog, instead of the Material List Display Options dialog.


How do I get to the Material List Display Options dialog box so that I can make certain categories of my materials list visible or invisible?

## ANSWER


The Material List Display Options dialog is used to make certain categories visible or invisible, depending on your needs. In order to access this dialog box, you must first create a new Materials List.

Once the materials list is open, you will be able to access the dialog box. Use the following procedure to access the Material List Display Options dialog box.


To access the Material List Display Options dialog

1. To create the materials list from your plan, select **Tools> Materials List> Calculate From All Floors** .

This will generate a Materials List. Once the Materials List has generated, you will have full access to each of the menu items.

2. With the Materials List open, select **Tools> Display Settings> Display Options**  from the menu to open the Material List Display Options dialog.

3. Within this box you will be able to make the categories of your choice visible or invisible.



In doing so, you will be able to isolate certain categories for the purposes of printing, examination or modification.

4. Click **OK** when finished.

208-292-3400 (tel:+1-208-292-3400) © 2003–2017 Chief Architect, Inc.

[Terms of Use \(https://www.chiefarchitect.com/company/terms.html\)](https://www.chiefarchitect.com/company/terms.html)

[Privacy Policy \(https://www.chiefarchitect.com/company/privacy.html\)](https://www.chiefarchitect.com/company/privacy.html)