# Displaying Dimensions in Inches

Reference Number: **KB-01018**Last Modified: **May 24, 2022** 

This article also applies to the following legacy products:

Pro | Architectural | Suite

## **QUESTION**

I would like to create dimension lines that display only in inches. How can I accomplish this?


## **ANSWER**

In Home Designer, you have the ability to set your Dimension Defaults to display dimensions in feet and inches, feet, or just inches.

### To access the Dimension Defaults


- 1. Select **Edit> Default Settings**  $\begin{picture}(10,0)\put(0,0)\pu$
- 2. Select the **Dimension** category to highlight it, then select the **Edit** button to open the **Dimension Defaults** dialog.

In Home Designer Pro 2021 and prior versions, expand the Dimension category, select Dimensions, then click the Edit button.



3. On Format panel, use the **Units** drop-down menu and select " to have all created dimensions show inches only (example: 37" instead of 3'-1").

In Home Designer 2023 and newer versions, various fractional styles are also available, including horizontal, diagonal, and vertical.



4. Click **OK** and **Done** to confirm the change and close the dialogs.

#### Related Articles

- **≜** Changing Your Dimension Settings (/support/article/KB-00491/changing-your-dimension-settings.html)
- **≜** Deleting Dimensions (/support/article/KB-00139/deleting-dimensions.html)
- **<u>4** Using the Dimension Tools (/support/article/KB-01002/using-the-dimension-tools.html)</u>

© 2003–2025 Chief Architect, Inc. All rights reserved // <u>Terms of Use (https://www.chiefarchitect.com/company/terms.html)</u> // <u>Privacy Policy (https://www.chiefarchitect.com/company/privacy.html)</u>