

Creating a Transom and Side Lites for a Door

Reference Number: **KB-01262**

Last Modified: **July 21, 2021**

The information in this article applies to:



QUESTION

I would like to add a transom and side lites to a door in my plan. How do I do this?






ANSWER

In Home Designer, a selection of entryways with transoms and side lites can be found in the Library Browser under Home Designer Core Catalogs> Architectural> Doors and Doorways> Entryways.


However, if you do not find a doorway that suits your needs in the library, you can create one yourself using the Door and Window Tools


To create a door with side lites


1. **Open**  the Home Designer plan in which you would like to create an doorway with side lites and a transom.
2. Select **Build> Door> Hinged Door**  from the menu, then click once on the entry wall to place a door at that location.




3. With the door selected, click the **Open Object**  edit button and in the **Door Specification** dialog that opens:



- On the **GENERAL** panel, specify the **Width** and **Height** that you would like your entry door to be.
 - On the **MATERIALS** panel, specify the materials that you would like applied to this door.
 - Make any other changes that you would like, then click **OK** to close the dialog.
4. Select **Build> Window> Window**  and click once on the wall of your entry to create a window at that location. This window will become a side lite.




- If you are not able to place the window on the entry wall because the area is too constricted, temporarily move the door to one side.
- If there is still too little room, place the window in another wall where there is enough room, make the window smaller, then copy and paste it onto the entry wall.

5. Click on this window to select it, then click the **Open Object**  edit button.


6. In the **Window Specification** dialog that displays, make any necessary changes to this window, as it will serve as one of the side lites.


- On the **GENERAL** panel, set the **Window Type**, **Width**, **Height**, and the **Floor to Top** value.



For this example, the Window Type is set to Fixed Glass, the Width is set to 12", and the Height is set to 42". We also want to make sure that the window's Floor to Top height is the same as the door's height.



- On the **SILL** panel, uncheck **Use Interior Sill** and **Use Exterior Sill**.
- Choose to add lites to the window on the **LITES** panel.
- Make any other necessary changes then click **OK** to close the dialog.


7. Click on the window to select it, then click the **Copy/Paste**  edit button. Click once on the other side of the door to place an exact copy of the window at that location.




8. If necessary, click on each window and use the **Move**  edit handle that displays at its center to slide it towards the door.
9. Select **3D> Create Perspective View> Full Camera**  from the menu and click and drag a camera in the direction of the entry door and side lites.




To create a transom

1. Select **Build> Window> Window**  and click once on a wall near your entry to create a window at that location. This window will become the transom and will be moved into position, so its location at this time is not important.




- If there is too little room on the entry wall to place this window, place it in another wall where there is enough room, edit it as described below, then copy and paste it onto the entry wall.

2. Click on this window to select it, then click the **Open Object**  edit button.

3. In the **Window Specification** dialog that displays:



- On the **GENERAL** panel, specify the **Width**, **Height**, and **Floor to Top** that you would like the transom window to be.


For this example, the Window Type is set to Fixed Glass, the Width is set to 68", the Height is set to 12", and the Floor to Top value is set to 96".



The exact size and height aren't important now, but you do want this window to be high and narrow enough that it will fit between the ceiling of the room inside the door and the top edge of the door and side lites.

- On the **OPTIONS** panel, specify the **Vertical Stacking** as Level 1.
- On the **SILL** panel, uncheck **Use Interior Sill** and **Use Exterior Sill**.
- Choose to add lites to the window on the **LITES** panel.
- Click **OK** to close the dialog and apply your changes.

- Using the **Select Objects**  tool, click on the transom window to select it, click the **Center Object**  edit button, then click once on the middle of the door to center it on the door.



- Select **3D> Create Perspective View> Full Camera**  from the menu and click and drag a camera arrow in the direction of the entryway to see the results.



© 2003–2021 Chief Architect, Inc. All rights reserved // [Terms of Use \(https://www.chiefarchitect.com/company/terms.html\)](https://www.chiefarchitect.com/company/terms.html) // [Privacy Policy \(https://www.chiefarchitect.com/company/privacy.html\)](https://www.chiefarchitect.com/company/privacy.html)