

Creating Stair Winders

Reference Number: **KB-00486**

Last Modified: **July 22, 2021**

The information in this article applies to:



QUESTION

I have some triangular shaped steps, or winders in my plan. How can I model these?



ANSWER


Winders are steps located where a staircase turns and are narrower on the inside of the turn than they are on the outside. A staircase defined as a winder expands to fill in any gaps between the side of the stairs and nearby walls. Winders can be created a variety of different ways:

- [Creating winders automatically for L and U-shaped staircases*](#)
- [Creating stair winders manually using landings](#)
- [Adding winders using the Staircase Specification in Home Designer Pro](#)

Creating winders automatically for L and U-shaped staircases*


*Applies to Home Designer 2021 and newer program versions.

1. Select **Build> Stairs> L-Shaped Stair**  or **Build> Stairs> U-Shaped Stair**  from the menu.
2. In the **New Shaped Staircase** dialog that opens, check **Make Winders**, then click **OK**. This will split the landing into 2 winders for an L-shaped staircase and 4 winders for a U-shaped staircase.





Note: The U-Shaped Stairs section only applies when using the U-Shaped Stair tool. It can be ignored when creating L-shaped stairs.


3. Place the stairs wherever you want them and then you'll see your staircase with winders.





Creating stair winders manually using landings



1. Select **Build> Stairs> Straight Stairs** , then click and drag to create a section of stairs with the number of treads leading up to the winder section.





2. Using the **Straight Stair**  tool, draw another section of stairs from where the top end of the winder would be to finish the staircase.



3. Select **Build> Stairs> Landing**  tool and click to place a landing on your floor plan.




4. Select the landing and use the diamond edit handles to reshape it into the shape of the winder step.





5. Using the square edit handle in the middle of the landing, move the landing into position with the stairs. The

stairs and landing should automatically connect to one another once they are close enough to each other. Continue creating landings, reshaping them, and moving them into position until all your winders are completed.




Adding winders using the Staircase Specification in Home Designer Pro


1. Select **Build> Stairs> Straight Stairs** , then click and drag to create a section of stairs with the number of treads leading up to the winder section.





2. Starting at the top of the stairs, create a second stair section, drawing in the same direction as the original. This second section will become the Winders, be sure to draw the appropriate number of treads to fit your specific need.




3. Click to select the stairs, then click and drag the move the topmost center edit handle, holding the **Alt** key on your keyboard or the **Option** key if you are on a Mac to create a curve in the winder section.



- Using the **Straight Stair**  tool, draw another section of stairs at the top end of the winder to finish the staircase.



- Move the staircase into the corner you want it placed, and with it selected, click on the **Open Object**  edit tool.
- In the **Staircase Specification** dialog that displays, check the **Winders** box.

Interior Staircase Specification

General


- Style
- Stringers
- Railing
- Newels/Balusters
- Rails
- Line Style
- Fill Style
- Materials
- Arrow
- Components

Staircase Information

Shallow staircase reaches next level.
 Best fit riser height of 6 3/4" requires 17 total risers to reach 114 5/8" to next level.

Number of Sections: 1
 Number of Landings: 0
 Number of Risers: 20
 Rise Angle: 29.04

Make Best Fit




Advanced Options

- Automatic Treads
- Lock Tread Depth
- Lock Number of Treads
- Automatic Heights
- Top Height Reference
 - Floor/Landing
 - Top Tread
- Ignore Subsection Boundaries
- Lock Top
- Lock Bottom

Section Number	Length	Width	Tread Depth	Treads	Bottom Height	Top Height	Riser Height	Winders
<input checked="" type="radio"/> 1-1	82 9/16"	39"	10 5/16"	8	7/8"	115 1/2"	5 3/4"	<input type="checkbox"/>
<input type="radio"/> 1-2	46 1/8"	39"	11 1/2"	4	7/8"	115 1/2"	5 3/4"	<input checked="" type="checkbox"/>
<input type="radio"/> 1-3	76 3/16"	39"	10 7/8"	7	7/8"	115 1/2"	5 3/4"	<input checked="" type="checkbox"/>

7. Click **OK** to apply the change, and the winders will now snap into the corner.



Winders must be in a room with valid room definition. You cannot create winders in an area composed of only 2 corner walls. If this configuration is needed, enclose the area in with Invisible walls so that a room area is defined.

🏠 [Creating a Staircase \(/support/article/KB-00420/creating-a-staircase.html\)](/support/article/KB-00420/creating-a-staircase.html)

🏠 [Creating Staircases Connected by Landings \(/support/article/KB-00263/creating-staircases-connected-by-landings.html\)](/support/article/KB-00263/creating-staircases-connected-by-landings.html)

🏠 [Creating, Moving, and Deleting Stairwells \(/support/article/KB-00125/creating-moving-and-deleting-stairwells.html\)](/support/article/KB-00125/creating-moving-and-deleting-stairwells.html)