


Creating a French Door

Reference Number: **KB-00134**

Last Modified: **September 6, 2019**

The information in this article applies to:



QUESTION




How can I create a simple 15 lite French Door?



ANSWER

A standard French Door can be easily created using the standard Door Tools.

To create a French Door

1. Open the plan in which you would like to create a French door.
2. Select **Build> Door> Hinged Door**  from the menu and click on a wall to place a standard door at that location.
3. Click the **Select Objects**  tool, then click on the door to select it and click the **Open Object**  edit button.
4. In the **Exterior Door Specification** dialog:
 - On the **GENERAL** panel, click the **Door Style** drop-down arrow and select **Glass Panel** from the list.
 - Under **Panel Frame Options**, change the **Bottom** value to 4"

Exterior Door Specification

General

Door Style: Glass Panel Library...

Door Type: Hinged

Swing Angle: 90°

Size and Position

Width: 36"

Height: 80"

Thickness: 1 3/4"

Elevation Reference: From Floor

Floor to Top: 80"

Floor to Bottom: 0"

Sliding Doors

Side Overhang: 0"

Top Overhang: 0"

Offset From Wall: 0"

Panel Frame Options

Width: 4"


Bottom: 4"

Options

Door Symbol: Reverse Interior/Exterior

Double the Width of the door in the Door Specification dialog to automatically create a double french door at this location.


- On the LITES panel, change the **Lites Across** value to 3 and **Lites Vertical** to 5.




5. Click **OK** to close the dialog and apply your changes.

6. Finally, take a 3D **Full Camera**  view of the door to view the results.

Related Articles

 [Changing the Hinge Side or Swing Direction of Doors \(/support/article/KB-00294/changing-the-hinge-side-or-swing-direction-of-doors.html\)](/support/article/KB-00294/changing-the-hinge-side-or-swing-direction-of-doors.html)

 [Creating a Transom and Side Lites for a Door \(/support/article/KB-01262/creating-a-transom-and-side-lites-for-a-door.html\)](/support/article/KB-01262/creating-a-transom-and-side-lites-for-a-door.html)