Converting a Plot Plan Polyline to a Terrain Perimeter

Reference Number: **KB-00323**Last Modified: **November 27, 2024**

This article also applies to the following legacy products:

Pro

QUESTION

In plan view I have created my plot plan using the <u>CAD</u> tools. How do I convert this polyline to a terrain perimeter?

ANSWER

Closed polylines can be converted to a terrain perimeter using the Convert Polyline dialog.


To convert a polyline to a terrain perimeter

1. If you already have an existing polyline in the plan file that you want to convert, use the **Select Objects** tool to select it, then click on the **Convert Polyline** 4 edit tool.

Note: A polyline must be fully closed before it can be converted to a terrain perimeter.

2. In the Convert Polyline dialog that displays next, select the Terrain Perimeter option, then click OK.

Note: If this option is grayed out and unselectable, you either already have a terrain perimeter in your plan or you do not have a closed polyline selected. Since only one terrain perimeter can be placed in a plan, you must delete the existing terrain perimeter before you can convert a polyline into one.



- 3. After you click **OK**, the **Terrain Specification** dialog will display, where you will be able to change the specifications for your terrain to suit your needs for this particular plan.
- 4. Click **OK** once you are finished, then take a **Camera o** view to see your terrain in 3D.

Related Articles

- **d** Creating a Plot Plan in Home Designer Pro (/support/article/KB-00576/creating-a-plot-plan-in-home-designer-pro.html)
- <u>■ Importing, Resizing, and Tracing Over an Image or PDF of a Floor Plan(/support/article/KB-00018/importing-resizing-and-tracing-over-an-image-or-pdf-of-a-floor-plan.html)</u>